

Assembly instruction for the passenger Connection Box for the CB-Radio

The assembly set contains the following items

1. Passenger Connection Box
2. Dual distributor
3. Connection cable from manifold to Connection Box
4. Plug cable for PPT switch (passenger control unit)

A passenger control unit or at least a sensing device is necessary to operate this device.

Assembly instructions

Dismantle the seat.

Disconnect the 8 pole connection plug of the CB-Radio (HF module) to the driver Connection Box and connect with the dual distributor of the CB-Radio. Insert both connection cables (for driver Connection Box and passenger Connection Box) into the dual distributor.

Disconnect the last Intercom cable and insert the driver Connection Box into the now open socket. Forward the cable of the dual distributor to the Connection Box and connect them. Also forward the cable of the passenger switch (passenger control unit).

Make a speech test with a second (hand) CB-Radio. Test the AM and the FM mode.

Secure installed cables and mount the dismantled parts.

Both headsets can be used for listening and speaking. The PTT switches are connected parallel. No matter which switch is used, both driver and passenger can speak. While transmitting or receiving the connection of both headsets to the Intercom or the radio is interrupted. It is not possible to listen to spoken passages while transmitting information.

In case of occurring problems, please do not hesitate to contact us at +49(0)4122 967690. We help you.

